

Lab Access Instructions

Introduction

This lab runs on a virtualised environment for Cisco IOS called "Dynamips".

To join the network which the lab environment is on, associate your laptop with the wireless network called **IPv6**. The password for this network is **8888888888** - this is ten times the number **8**.

The method of access to each virtual router is via Telnet to a specific port on the IP of the machine that runs the virtualization platform.

For example:

```
$ telnet 10.10.0.241 2012
```

Dynamips Port to Router Console Map

Port	Router
2001	TR1
2002	TR2
2011	B1
2012	C1
2013	P1
2014	A1
2021	B2
2022	C2
2023	P2
2024	A2
...	...

Login instructions

After executing the telnet command, you will see something like the following:

```
Trying 10.10.0.241...
Connected to 10.10.0.241.
Escape character is '^]'.
Connected to Dynamips VM "P2" (ID 8, type c7200) - Console port
```

Press ENTER at this point. Then, if you see this question:

```
Would you like to enter the initial configuration dialog? [yes/no]:
```

Answer "no".

The router will show some initialization routines, and finally, you will see the default prompt:

```
Router>
```

You can then go into privileged mode:

```
Router> enable  
Router#
```

And then enter configuration mode:

```
Router# configure terminal  
Router(config)#
```

And you are ready to start entering configuration statements. When you are done, exit configuration mode by typing `*end*` or pressing `*ctrl-Z*` and save your changes:

```
Router(config)# end  
Router# write memory
```

[Back to Agenda page](#)

From:

<https://bgp4all.com.au/pfs/> - **Philip Smith's Internet Development Site**

Permanent link:

<https://bgp4all.com.au/pfs/training/apnic-ipv6-nc/lab-access?rev=1521444369>

Last update: **2018/03/19 07:26**

